LIGHT FITTINGS

MAST LID

WIRE ROPE

MAST BASE

MAST TOP

INTERNAL DISTRIBUTION BOARD

PORTABLE HANDWINCH ENSURING THAT DURING MAINTENANCE THE SYSTEM IS SUSPENDED ON THE WIRE ROPE.

DOOR OPENING CONCEALED BEHIND LID WHEN CLOSED

MID-HINGE MAST IN CLOSED POSITION

MID-HINGE MAST IN OPENED POSITION

LIGHTNING SPIKE

lighting STRUCTURES

MIDHINGE MAST